

---

# **mcu-uuid-common**

**Jun 02, 2021**



---

## Contents

---

<b>1 Description</b>	<b>1</b>
<b>2 Purpose</b>	<b>3</b>
<b>3 Contents</b>	<b>5</b>
<b>4 Resources</b>	<b>7</b>



# CHAPTER 1

---

Description

---

Microcontroller common utilities library



## CHAPTER 2

---

### Purpose

---

The primary purpose of this library is to maintain a common 64-bit uptime in milliseconds with overflow handling, as long as the loop function is called regularly.





## 3.1 Usage

```
#include <uuid/common.h>
```

Call `uuid::loop()` regularly and then call `uuid::get_uptime_ms()` when the uptime is required.

### 3.1.1 Example

```
#include <Arduino.h>
#include <uuid/common.h>

class Uptime: public Printable {
public:
    Uptime(uint64_t timestamp_ms = uuid::get_uptime_ms())
        : timestamp_ms_(timestamp_ms) {}

    size_t printTo(Print &print) const override {
        unsigned long days;
        unsigned int hours, minutes, seconds, milliseconds;
        uint64_t timestamp_ms = timestamp_ms_;

        days = timestamp_ms / 86400000UL;
        timestamp_ms %= 86400000UL;

        hours = timestamp_ms / 3600000UL;
        timestamp_ms %= 3600000UL;

        minutes = timestamp_ms / 60000UL;
        timestamp_ms %= 60000UL;
    }
};
```

(continues on next page)

```
seconds = timestamp_ms / 1000UL;
timestamp_ms %= 1000UL;

milliseconds = timestamp_ms;

size_t len = print.print(F("Uptime: "));
len += print.print(days);
len += print.print('+');

char time[2 + 1 /* hours */
          + 2 + 1 /* minutes */
          + 2 + 1 /* seconds */
          + 3 /* milliseconds */
          + 1] = { 0 };
int ret = snprintf_P(time, sizeof(time), PSTR("%02u:%02u:%02u.%03u"),
                    hours, minutes, seconds, milliseconds);
if (ret > 0) {
    len += print.print(time);
}
return len;
}

private:
    uint64_t timestamp_ms_;
};

void setup() {
    Serial.begin(115200);
}

void loop() {
    uuid::loop();

    Serial.println(Uptime());

    delay(1000);
}
```

## Output

```
Uptime: 0+00:00:00.000
Uptime: 0+00:00:01.000
Uptime: 0+00:00:02.000
Uptime: 0+00:00:03.000
Uptime: 0+00:00:04.000
Uptime: 0+00:00:05.000
Uptime: 0+00:00:06.000
Uptime: 0+00:00:07.000
Uptime: 0+00:00:08.000
Uptime: 0+00:00:09.000
Uptime: 0+00:00:10.000
```

## 4.1 Change log

### 4.1.1 Unreleased

### 4.1.2 1.1.0 – 2019-09-15

Printable to string functions.

#### Added

- Functions to output a `Printable` to a `std::string`.

#### Changed

- Put each function in a separate file to improve linker behaviour.

### 4.1.3 1.0.2 – 2019-08-16

Fix example.

#### Fixed

- Example now prints the time part of the uptime instead of ignoring it.

### 4.1.4 1.0.1 – 2019-08-15

Update example and add tests.

### Added

- Test builds of the example.
- Unit tests of the uptime overflow handling.

### Changed

- Exclude the test directory from exports of the library source code.

### Fixed

- Remove use of `Serial.printf()` from the example (which does not exist in the standard Arduino library).

## 4.1.5 1.0.0 – 2019-08-11

First stable release.

### Added

- Function `void uuid::loop()` that should be called regularly.
- Function `uint64_t uuid::get_uptime_ms()` to get the current uptime as a 64-bit milliseconds value.
- Function `std::string uuid::read_flash_string(const __FlashStringHelper *flash_str)` to convert flash strings to `std::string`.
- Type `uuid::flash_string_vector` for a `std::vector` of flash strings.